

Daikin VRV SYSTEMS Compatibility List



Document Version: 2.1 Last Updated: 28.04.2022

Device Version: 1.1

Device Model: CR-CG-DK-KNX-01

www.core.com.tr



1. INTRODUCTION

In this document, compatible Daikin VRV indoor unit models with Core Daikin VRV Gateway (CR-CG-DK-KNX-01) are specified.



Any AC indoor unit not specified in the list may not be compatible with Core AC Gateway. Therefore compatibility list must be checked before installation.



Any remote controller not specified in the list may not be compatible with Core AC Gateway. Therefore compatibility list must be checked before installation.



We highly recommend to pay attention to the possible updates of this document in case of any misprint, typing error and equivalent problems.



Core Smart Home undertakes maximum effort to avoid any error in the content of this document but cannot be responsible for the consequences that could arise because of anny mistake in the document.

www.core.com.tr



2. COMPATIBLE AC INDOOR UNITS

INDOOR UNIT TYPE	VRV LINE INDOOR UNIT MODEL
Ceiling Mounted Cassette 2-Way	FXCQ xx
	FXYC xx
Ceiling Mounted Cassette 4-Way	FXZA xx
	FXZQ xx
	FXYF xx
Ceiling Mounted Cassette Corner	FXKQ xx
	FXYK xx
Ceiling Suspended Unit 4-Way	FXUQ xx
Ceiling Mounted Cassette Round Flow	FXFA xx
	FXEQ xx
	FXFQ xx
	FXFSQ xx
Ceiling Suspended Unit	FXHQ xx
	FXYH xx
Ceiling Mounted Build-In	FXTQ xx
Ceiling Concealed Unit Slim	FXDA xx
	FXDQ xx
Ceiling Concealed Unit	FHEYB xx
	FXYB xx
	FXYM xx
	FXYS xx
	FXYSP xx
Ceiling Concealed Unit Large	FXMQ xx
Ceiling Concealed Unit Inverter Driven	FXSA xx
	FXSQ xx
Floor Standing Unit Without Casing	FXNQ xx
	FXLQ xx
Floor Standing Unit With Casing	FXYL xx
	FXYLM xx
Wall Mounted Unit	FXAA xx
	FXAQ xx
	FXYA xx
Air Curtain	CAS xx



XX stands for power of the indoor unit.



3. COMPATIBLE REMOTE CONTROLLERS

WIRED REMOTE CONTROLLERS WORK WITH CORE DAKIN KNX GATEWAY ON THE SAME BUS	
BRC1A52	
BRC1D52	
BRC1E51A	
BRC1E52	
BRC1E52A	
BRC1E52B	
BRC1E53A	
BRC1E53B	
BRC1E53C	
BRC1E63	
BRC1E73	
BRC1H519	
BRC1H519W	
BRC1H52	
BRC1H52W	

4. INSTALLATION SCENARIOS

INSTALLATION WITH DAIKIN WIRED REMOTE CONTROLLERS

Connect Core AC Gateway parallel with Daikin wired remote controllers. In this method, Daikin Wall controller should be programmed as master, while Core AC Gateway programmed as slave.

INSTALLATION WITHOUT DAIKIN WIRED REMOTE CONTROLLERS

Connect Core AC Gateway directly to the P1,P2 connectors of the Daikin indoor unit. In this scenario, Core AC Gateway should be programmed as Master.

www.core.com.tr